



“like water off a duck`s back”

## **PCT<sup>®</sup> FIBRE WATERPROOFING**

PRODUCT CODE D-015

### **APPLICATION PROCEDURE**

#### **SURFACE PREPARATION.**

- Identify the areas to be treated.
- Thoroughly remove all dust, dirt or any foreign debris. Note that cracks and crevices normally contain large amounts of dust, dirt and mud deposits and if not washed down thoroughly the treatment will fail.
- Wash down the entire area.
- Leave to dry.

#### **APPLICATION.**

- PCT FIBRE WATERPROOFING is a high solid viscous product with excellent filling properties.
- Carefully fill in the cracks and crevices with liberal amounts of PCT FIBRE WATERPROOFING by brush or trowel application application.
- Trim the leading edges and surrounding areas with wet a brush.

#### **MAINTENANCE.**

- In the event that mechanical damage has occurred, simply wash down the entire area to remove all dust, dirt or foreign debris.
- Patch repair the damaged area in accordance with the application procedure.

The information contained in this document is meant as a guide for the specifier or user. It is gained from laboratory tests conducted in controlled environment and experience. No guarantee of performance is implied since application procedure, conditions of use, substrate condition and substrate cleanliness is beyond our control.

#### **MANUFACTURED BY:**

PCT WATER REPELLENT TECHNOLOGY CC

#### **DISTRIBUTED BY:**

MARVEL COATINGS  
5 LOUIS TRICHARD STR  
EXTENSION 10  
WITBANK  
1035

Tel: 013 656 4994

Fax: 086 623 7944

Cell: 072 404 1625

e-mail: [info@marvelcoatings.co.za](mailto:info@marvelcoatings.co.za)

web: [www.marvelcoatings.co.za](http://www.marvelcoatings.co.za)